



Dimensional Changes in Wood

Salim Hiziroglu

Assistant Professor, Wood Products

From early Paleolithic times, wood has been one of the most important raw materials for making everything from furniture to weapons to art. The availability of metal tools about 5000 BC gave Egyptians the ability to improve the art of cutting veneer pieces to use in construction of various products. Although wood uses and processing techniques have been developing for millennia, the science of wood technology is relatively new.

Wood is a hygroscopic material which loses and gains moisture as a result of changes in humidity. Hygroscopicity is one of the most distinctive properties of wood. Any kind of wood product will absorb and desorb moisture from the surrounding air until it reaches equilibrium moisture content, a balance point between the wood's moisture content and that of the surrounding environment. Hygroscopic materials such as wood and other lignocellulosic material change their dimensions with fluctuations in relative humidity. Therefore, determination of moisture content of wood products before they are used is an important task. Based on the current moisture content of wood and its surrounding conditions, dimensional changes in wood will take place, influencing its effectiveness as a construction material.

Water in wood

Water in freshly cut harvested wood is located within the cell wall and the cell lumen. Water found in the cell wall is called bound water, while water in the lumen is referred to as free water. (See Figure 1.) Free water is quite simple to remove; as soon as a tree is cut, free water begins to evaporate. The water in the cell wall is held by adsorption force which involves the attraction of water molecules to hydrogen bonding in cellulose, hemicellulose, and lignin.

The amount of water in wood is referred to as its moisture content (MC) and is defined as weight of the water present, expressed as a percentage of the moisture-free or oven dry weight of the wood. MC can be determined using various methods. Standard oven dry methods and electrical moisture meters are the most commonly used techniques. Chemical and distillation methods can also be used to determine moisture content of wood; however, they are usually confined to laboratory use.

The most accurate technique to measure MC of wood is the oven dry method. Individual specimens of wood to be tested are weighed on a balance and placed in a ventilated oven set at just above the boiling point of water, 103± 2°C (219°F). Samples are kept in the oven until they reach a constant weight, which usually takes 24–48 hours. The new weight is called oven dry weight and is then used to calculate

Oklahoma Cooperative Extension Fact Sheets are also available on our website at: <http://osufacts.okstate.edu>




Figure 1. Location of water in a cell.

MC in the sample. MC calculated in this way could be over 100% because the denominator in the equation is the dry weight, not the total weight. By way of example, if a 3 x 3 x 5-inch oak sample weighs 1.0 lb. and its oven dry (OD) weight is 0.70 lb., its MC is :

$$MC = \frac{\text{Weight (M)} - \text{Weight (OD)}}{\text{Weight (OD)}} \times 100$$

$$MC = [(1.0 - 0.7) \div 0.7] 100 = 42.8\%$$

Shrinkage and swelling of wood

Dimensional changes, shrinkage, and swelling in wood take place below the fiber saturation point (FSP) where all of the water exists only within the cell wall (Figure 1). For sim-

plicity, shrinkage and swelling will be combined and referred to collectively as shrinkage here. Shrinkage is proportional to the amount of water exchanged between a piece of wood and its environment. Wood is an anisotropic material; that is, its dimensions change differently in three directions: tangentially, radially, and longitudinally. Tangential dimensional change has the highest rate of change due to parallel orientation of microfibrils along the axis of the cell wall. Shrinkage in the radial direction is the second largest, while longitudinal shrinkage is negligible for most practical applications. A schematic approach to the swelling of a block in three directions is shown in Figure 2. In general, dimensional change is expressed as percent and can be calculated using the following formula:

$$\text{Shrinkage or swelling (\%)} = \frac{\text{Change in dimension or volume}}{\text{Initial dimension or volume}} \times 100$$

Dimensional changes can also be estimated based on the following equation:

$$\text{DC} = \text{OD} \times \text{SV} \times (\text{CMC} \div \text{FSP}) \times 100$$

where DC is dimensional change due to change in moisture content (CMC), OD is original dimension, SV is shrinkage value from green to oven dry moisture content, and FSP is fiber saturation point, which is considered 28% for practical purposes. Table 1 displays shrinkage and swelling values from green to oven dry moisture content for some of the most commonly used species.

There is a direct relationship between density of wood and shrinkage values. Species with higher density shrink more than those with lower density. Even though shrinkage values of many species are relatively low, they still play a significant role in designing wood structures. If shrinkage of wood is not taken into consideration during the design stages, certain construction defects such as warping, cracking, and buckling may easily occur, lowering the overall quality of the finished product.

If we assume that lumber production in the U.S.A. is approximately 40 billion board-feet per year on average, and assuming volumetric shrinkage due to moisture content change of four percent, we would expect to lose 1.6 billion board feet of material per year. This hypothetical example emphasizes the importance of accounting for shrinkage in wood products.

Dimensional stabilization of wood is needed for special applications. Thermosetting resins that are highly water resistant are normally used for this purpose. There have been many studies aimed at stabilizing the cell wall so that shrinkage of wood can be controlled. Resin-treated wood, resin-treated compressed wood, untreated compressed wood, wood treated with polyethylene glycol, and wood polymer composites are some of the means used to reduce or eliminate cell wall shrinkage. However, none of these methods has been put into practical use due to economical and technical considerations.

When shrinkage values of different species are taken into design consideration, disadvantageous characteristics of wood can be handled properly. Figure 3 shows a hypothetical panel consisting of three species in both radial and tangential grain orientation.




Figure 2. Swelling of a block in three directions.

If this construction has an average moisture content of 5% and its moisture is increased to 15%, swollen length of the panel can be estimated as follows:

White oak : $3 \times 0.056 \times (0.10 \div 0.28) = 0.060$ in.
 American elm : $4 \times 0.095 \times (0.10 \div 0.28) = 0.135$ in.
 Yellow poplar : $2 \times 0.046 \times (0.10 \div 0.28) = 0.033$ in.

The length of the panel after exposure to higher moisture will be :

$$9 + 0.060 + 0.135 + 0.033 = 9.228 \text{ in.}$$

If this panel were restrained on a wall under these moisture conditions, buckling could occur unless a gap is left within the framework of the panel.

Conclusion

Wood will shrink and swell as the result of moisture content change in the surrounding environment. Shrinkage of wood

Table 1. Tangential and radial shrinkage values from green to oven dry moisture content.

<i>Species</i>	<i>Tangential (%)</i>	<i>Radial (%)</i>
American Elm	9.5	4.2
Sugar Maple	9.9	4.8
Black Oak	11.1	4.4
Red Oak	8.9	4.2
White Oak	10.5	5.6
Black Walnut	7.8	5.5
Yellow Poplar	8.2	4.6
Black Cherry	7.1	3.7
Sweetgum	10.2	5.3
Eastern Redcedar	4.7	3.1
Western Redcedar	5.0	2.4
White Fir	7.1	3.2
Eastern Hemlock	6.8	3.0
White Pine	7.4	4.1
Ponderosa Pine	6.2	3.9
Redwood	4.5	2.5
Spruce	7.5	4.3
Balsa	7.6	3.0
Ramin	8.7	3.9
Teak	4.0	2.2
Mahogany	5.1	3.7




Figure 3. Each piece will have a different swollen length due to its grain orientation when overall moisture content of the construction is increased 10%. Swollen length of the panel is a function of moisture content change and physical properties of species.

and wood products is one of the most important design parameters to consider in order to eliminate future defects in the product. As long as this inherent problem is properly treated, one of our most important renewable materials can be used efficiently for many applications without major problems.

The Oklahoma Cooperative Extension Service

Bringing the University to You!

The Cooperative Extension Service is the largest, most successful informal educational organization in the world. It is a nationwide system funded and guided by a partnership of federal, state, and local governments that delivers information to help people help themselves through the land-grant university system.

Extension carries out programs in the broad categories of agriculture, natural resources and environment; family and consumer sciences; 4-H and other youth; and community resource development. Extension staff members live and work among the people they serve to help stimulate and educate Americans to plan ahead and cope with their problems.

Some characteristics of the Cooperative Extension system are:

- The federal, state, and local governments cooperatively share in its financial support and program direction.
- It is administered by the land-grant university as designated by the state legislature through an Extension director.
- Extension programs are nonpolitical, objective, and research-based information.
- It provides practical, problem-oriented education for people of all ages. It is designated to take the knowledge of the university to those persons who do not or cannot participate in the formal classroom instruction of the university.
- It utilizes research from university, government, and other sources to help people make their own decisions.
- More than a million volunteers help multiply the impact of the Extension professional staff.
- It dispenses no funds to the public.
- It is not a regulatory agency, but it does inform people of regulations and of their options in meeting them.
- Local programs are developed and carried out in full recognition of national problems and goals.
- The Extension staff educates people through personal contacts, meetings, demonstrations, and the mass media.
- Extension has the built-in flexibility to adjust its programs and subject matter to meet new needs. Activities shift from year to year as citizen groups and Extension workers close to the problems advise changes.

Oklahoma State University, in compliance with Title VI and VII of the Civil Rights Act of 1964, Executive Order 11246 as amended, Title IX of the Education Amendments of 1972, Americans with Disabilities Act of 1990, and other federal laws and regulations, does not discriminate on the basis of race, color, national origin, gender, age, religion, disability, or status as a veteran in any of its policies, practices, or procedures. This includes but is not limited to admissions, employment, financial aid, and educational services.

Issued in furtherance of Cooperative Extension work, acts of May 8 and June 30, 1914, in cooperation with the U.S. Department of Agriculture, Robert E. Whitson, Director of Cooperative Extension Service, Oklahoma State University, Stillwater, Oklahoma. This publication is printed and issued by Oklahoma State University as authorized by the Vice President, Dean, and Director of the Division of Agricultural Sciences and Natural Resources and has been prepared and distributed at a cost of 20 cents per copy. 0607